





	sinciess of	the counting	plate ale au	Justavie. (	ob siep
The preserve	a a maitin ditu	of the lumin	and field is a	directable	

The pressure-sensitivity of the luminous field is adjustable.

The accoustical signal of the count confirmation can be switched off / on.

**2 Wolffhügel-disks** (black/white), magnifying glass and felt-tip pen are included in the delivery.



# **ColonyStar**

## Colony Counter with colored illumination

### **Optimal contrast conditions**

By the customization of the color (pat. pend.) and the brightness - an effortlessy work is made possible.

**Color choice:** 65 color variants, made from the primary colors red/green/blue - are available.

Brightness: The brightness can be adjusted in 65 steps.

#### Automatic counting

The counting impulse is activated by the pressuresensitive counting plate. The pressure sensitivity for the count can be adjusted. Any ordinary felt-tip pen can be used for the marking.

#### Counting plate, Ø 145 mm

Dazzle-free illumination by the use of high power LED. The irradiation is carried out both of below and sideways. No warming of the Petri dishes.

#### **Technical description**

Easy-to-clean plastic casing, height adjustable, illumination area of 145 mm Ø with 1 cm<sup>2</sup> and 1/9 cm<sup>2</sup> graduation. Petri dishes of up to 145 mm Øcan be used. The supplied reducing insert can be used for dishes with smaller diameters.



FUNCE

ColonyStar with reducing insert



Dimensions (LxHxW): 27,5 x 8 x 30cm Weight: appr. 1,7 kg Connected loads: 230 V/50 Hz

Ordering data: ColonyStar with accessories

Art. no: 8500

#### Following Accessories are included:

Magnifying glass	8501
Wolffhügeldisk, white	8502
Wolffhügeldisk, black	8505
Felt-tip marker	8504
Reducing insert	

Color and Brightness of the luminous field are adjustable.

